

MAC Access List Configuration Commands

Table of Contents

1	MAC Access List Configuration Commands.....	- 1 -
1.1	MAC Access List Configuration Task.....	- 1 -
1.1.1	Creating MAC Access List.....	- 1 -
1.1.2	Configuring Items of MAC Access List.....	- 1 -
1.1.3	Applying MAC Access List.....	- 2 -

1 MAC Access List Configuration Commands

1.1 MAC Access List Configuration Task

1.1.1 Creating MAC Access List

To apply the MAC list on the port, you must first create the MAC list. After the MAC access list is successfully created, you log in to the MAC access list configuration mode and then you can configure items of the MAC access list.

Perform the following operations to add and delete a MAC list in privilege mode:

Run	To
configure	Log in to the global configuration mode.
[no] mac access-list <i>name</i>	Add or delete a MAC list. name means the name of the MAC list.

1.1.2 Configuring Items of MAC Access List

You can use the **permit** or **deny** command to configure the **permit** or **deny** items of the MAC list. Multiple **permit** or **deny** items can be configured on a MAC list.

The mask of multiple items configured in a MAC list must be the same. Otherwise, the configuration may be out of effect (see the following example). The same item can only be configured once in the same MAC address.

Perform the following operations in MAC list configuration mode to configure the items of the MAC access list:

Run	To
[no] {deny permit} {any host <i>src-mac-addr</i>} {any host <i>dst-mac-addr</i>}[<i>ether</i>type]	Add/Delete an item of the MAC list. You can rerun the command to add or delete multiple items of the MAC list. any means any MAC address can be compatible; src-mac-addr means the source MAC address; dst-mac-addr means the destination MAC address.

	ethertype means the type of matched Ethernet packet.
exit	Log out from the MAC list configuration mode and enter the global configuration mode again.
exit	Enter the management mode again.
write	Save configuration.

MAC access list configuration example

```
Switch_config#mac acce 1
```

```
Switch-config-macl#permit host 1.1.1 any
```

```
Switch-config-macl#permit host 2.2.2 any
```

The above configuration is to compare the source MAC address, so the mask is the same. The configuration is successful.

```
Switch_config#mac acce 1
```

```
Switch-config-macl#permit host 1.1.1 any
```

```
Switch-config-macl#permit any host 1.1.2
```

```
Switch-config-macl#2003-11-19 18:54:25 rule conflict,all the rule in the acl should match!
```

The first line on the above configuration is to compare source MAC addresses, while the second line is to compare destination MAC addresses. Therefore, the mask is different. The configuration fails.

1.1.3 Applying MAC Access List

The created MAC list can be applied on any physical port. One port can only be applied with one MAC access list. The same MAC list can be applied to multiple ports.

Enter the privilege mode and perform the following operation to configure the MAC access list.

Run	To
-----	----

configure	Enter the global configuration mode.
interface f0/1	Log in to the port that is to be configured.
[no] mac access-group <i>name</i>	Apply the created MAC list to the port or delete the applied MAC list from the port. name means the name of the MAC access list.
exit	Enter the global configuration mode again.
exit	Enter the management mode again.
write	Save configuration.